


Series Q	System Schroff	4 TE	G04-Q01
		5 TE	G05-Q01
		6 TE	G06-Q01
Series P, HP	System Schroff	4 TE	G04-Q04
		5 TE	G05-Q04
		6 TE	G06-Q04



Series S, HR, HRL, PSS	System Schroff	12 TE	G12-S
	System Intermas	12 TE	F12-S
Series K, HRP, PSK	System Schroff	16 TE	G16-K
	System Intermas	16 TE	F16-K
Series LT, UT	System Schroff	28 TE	G28-T01




Series PSL	System Schroff	8TE	G08-L
	System Intermas	8TE	F08-L
PSL with opt. D	System Schroff	8TE	G08-L04-D
	System Intermas	8TE	F08-L04-D




BBM 60001_AC, 27-Jun-2015, page 1 of 2


Series Q	System Schroff	4 TE	G04-Q01
		5 TE	G05-Q01
		6 TE	G06-Q01
Series P, HP	System Schroff	4 TE	G04-Q04
		5 TE	G05-Q04
		6 TE	G06-Q04



Series S, HR, HRL, PSS	System Schroff	12 TE	G12-S
	System Intermas	12 TE	F12-S
Series K, HRP, PSK	System Schroff	16 TE	G16-K
	System Intermas	16 TE	F16-K
Series LT, UT	System Schroff	28 TE	G28-T01




Series PSL	System Schroff	8TE	G08-L
	System Intermas	8TE	F08-L
PSL with opt. D	System Schroff	8TE	G08-L04-D
	System Intermas	8TE	F08-L04-D




BBM 60001_AC, 27-Jun-2015, page 1 of 2

Series Q	System Schroff	6 U/5 TE	G05-6HE-Q01
Series P, HP	System Schroff	6 U/5 TE	G05-6HE-Q04




Series M, LH	Syst. Schroff	6U/8TE	G08-6HE-M02
Series S,HR,HRL,PSS	Syst. Schroff	6U/12TE	G012-6HE-S
Series K, HRP, PSK	Syst. Schroff	6U/16TE	G016-6HE-K



www.belpowersolutions.com

Series M, LH	System Schroff	8 TE	G08-M02
	System Intermas	8 TE	F08-M02




BBM 60001_AC, 27-Jun-2015, page 2 of 2


bel POWER SOLUTIONS & PROTECTION
a bel group

www.belpowersolutions.com

Series Q	System Schroff	6 U/5 TE	G05-6HE-Q01
Series P, HP	System Schroff	6 U/5 TE	G05-6HE-Q04




Series M, LH	Syst. Schroff	6U/8TE	G08-6HE-M02
Series S,HR,HRL,PSS	Syst. Schroff	6U/12TE	G012-6HE-S
Series K, HRP, PSK	Syst. Schroff	6U/16TE	G016-6HE-K



Assembly of the front panel:

Series M, LH	System Schroff	8 TE	G08-M02
	System Intermas	8 TE	F08-M02



BBM 60001_AC, 27-Jun-2015, page 2 of 2

bel POWER SOLUTIONS & PROTECTION
a bel group

www.belpowersolutions.com